

LeakAlertor[®] 6000

Please store this guide in your medicine cabinet for reference



front

The LeakAlertor that was installed for you is a smart device that electronically monitors your toilet for water wasting problems. When a problem is detected, you will be **alerted both visually and audibly...**

...before you leave the bathroom.

For repairs and service, please contact:

Warning: Removing the unit from the toilet will cause a continuous alert to sound until the unit is placed back in the tank.

Note: The LeakAlertor does not contain a camera or any type of recording device.

back

Alerts...

...occur only during the flush cycle

When the **GREEN LIGHT** – and only the **GREEN LIGHT** – is flashing during a flush, your toilet is functioning properly.

BUT...

...If the LeakAlertor is continuously beeping and flashing the **RED LIGHT**, immediately take the following action:

- 1) Shut off the water by turning this **knob** clockwise as far as possible.
- 2) Press the reset button to temporarily silence the LeakAlertor.
- 3a) If the toilet was **overflowing**, first remove the blockage. Then, turn the water back on by turning the knob fully counter-clockwise.
- 3b) If the toilet was **only running**, remove the tank lid and close the **flapper** by making sure it lays flat, as shown here. Once the flapper has been closed, turn the water back on.



If the LeakAlertor only beeps a few times whenever the toilet is flushed, please call the contact number during normal business hours at your earliest convenience.

For more information and videos about the LeakAlertor, visit www.leakalserter.com